
(P) 1800 805 062 (F) 02 4677 0558 info@airocle.com.au Airocle.com.au

# **MAINTENANCE REQUIREMENTS**

# 3 SERIES - Ridge and Slope Ventilators



## **General Description**

Airocle 3 Series Ventilators are performance-based low profile natural extract ventilators providing efficient natural ventilation due to known coefficient of discharges. Manufactured in accordance to Australian Standard AS2427 and CSIRO tested, they provide a roof mounted weatherproof ventilation solution adaptable to all forms of roof cladding.

#### Inspection Requirements for both Static and Operable Ventilators

An inspection of the 3 Series Ventilator should occur every six months or a shorter interval should be used in marine or other corrosive environments and areas where atmospheric fallout occurs. The inspection should cover, where applicable, the following;

- > Check vents for damage, wear, corrosion or residue build up.
- > Check and ensure that the vents and all components such as pulleys, hinges, latches, cables, struts, etc., are free from obstruction and capable of operation.
  - > Check guides, bearings, springs and hinges are well lubricated.
  - > Check actuators
  - > Check battery dates and capacities
  - > Check drain holes and internal drain channels are clear.
  - > Check ram dust covers are in place.
  - Check for any mesh or bird wire damage.
  - Check for any damage to sealant used.
  - > Any filters should be regularly checked for particle build up and cleaned every 6 months.

#### Cleaning Requirements for both Static and Operable Ventilators

Cleaning should be carried out every 6 months using the following procedure:

- Cold water hose down of surface dirt to the inclination surfaces
- Warm soapy detergent wash over all surfaces
- Clean cold water hose down
- Allow to air dry (do no not allow to air dry before rinsing off the detergent)

The above process must be carried out at least once every 6 months. Should the Ventilators be 500 metres or less from salt water environment then the process should be carried out at least once every 3 months.

**Please Note:** If ventilators are used for Fire/Heat and Smoke ventilation, the goods must be serviced and maintained according to AS1851 every six months by a competent person. This is an essential Australian Standard compliance requirement. This will involve additional requirements to the above.

All service/maintenance must be carried out by an authorised technician and service records kept. Failure to do so may void your warranty.

## For all necessary repairs call Airocle on 1800 805 062

15 Redbank Place PO BOX 583 PICTON NSW 2571 service@airocle.com.au

